

Dress "Emily"

Model 120-16
Sizes 36-48



PRINT THE CUT

1. Open the pattern PDF and set the control square to Page 1 with the setting "Original size" on DIN Print A4 paper (do not click on "Adjustment to page size"!)
2. Check the square – if it is 10x10 cm, print out the whole cut sheet.
3. Place all pages next to each other as indicated by the arrows and adhere them row by row along the boundary lines, then glue the rows together.
4. Compare the body measurements with the table measurements and cut out the cut parts in the appropriate size (the overview of the cut parts is on the pattern sheet). **Important:** Instructions do not include seam allowances, unless otherwise indicated.

SUPPLIES

- 2.0–2.2 m rayon, 135 cm wide
- Iron-on stabiliser H 180 (Vlieseline)
- 7 buttons, 18 mm in diameter
- 0.5–0.7 m elastic, 0.6 mm wide
- Remnant of tear-away stabiliser

Optional BERNINA accessories

- [Button sew-on foot 18](#)

CUTTING

- 1 2 × upper front part
- 2 2 × front skirt part
- 3 1 × neckline facing on the fold
- 4 1 × upper back part on the fold
- 5 1 × back skirt part on the fold
- 6 2 × front sleeve
- 7 2 × back sleeve

INSTRUCTIONS

1. Iron the stabiliser on the facings and the button facing and let them cool off thoroughly. Close the darts on the front part.
2. Iron the cut facing of the front parts and skirt part towards the wrong side. Close the shoulder and side seams of all front and back parts.
3. Gather the lower edges of the front and rear upper parts between the markings so that the width is matched with the upper edges of the skirt. Sew the upper and the skirt parts right side on right side together, and in doing so, also unfold the ironed button facings.
4. Sew the front edges of the facing for the neckline right side on right side on the facing of the upper front part. Sew the facing right side on right side along the neckline. Clip the curves, turn it over and iron it. Top-stitch the hem, the button facing and the neckline facing all around.
5. Hem the sleeves along the straight long edges. Align the long edges, underlay them with stabiliser and connect the sleeves with a zigzag bead from the top and the bottom up to the marking. Remove the stabiliser.
6. Close the sleeve seams. Gather the top shaping and sew in the sleeves. Hem the sleeves and leave a little opening at the lower sleeve seam. Insert an elastic and close it to a ring.
7. Sew the buttonholes in the upper flap: 1st button position as marked in the pattern, place two other in the upper part and four in the skirt part at an even distance. Sew the buttons on the front centre of the lower flap.



made to create **BERNINA**